

	<p>L.D.Varley Sundials and Weathervanes A.B.N. 98 827 102 049 20 Park Crescent Boronia 3155 Melbourne. Australia Phone 03 9761 1971 Mobile 0419 399 404 Email varley@cosmos.net.au Web www.acmefluid.com.au/larry/weathervane.html</p>	
---	--	---

Sundial specifications and installation instructions

Sundial material Gunmetal Bronze

Sundial calibration Latitude 37.8 degrees (Melbourne and points east and west)

Sundial size 300mm square

Place the sundial in a location that will provide as many hours of direct sunlight as possible

The sundial should be mounted on a level surface

Position the sundial so that the north indicator faces true north, which is approximately 11 degrees west of magnetic north (a compass will indicate magnetic north)

The sundial will last indefinitely in the open air and will age gracefully from the polished appearance when new, to a warm bronze patina.